


# TRX Quick Start Guide



TRX

Strain Gauge Sensor Display



**APPLIED MEASUREMENTS LTD.**  
*Transducer Specialists...*

appmeas.co.uk | info@appmeas.co.uk | +44 (0) 118 981 7339

<b>Introduction/overview .....</b>	<b>2</b>
<b>Getting started.....</b>	<b>3</b>
Hardware overview.....	3
Front.....	3
Back.....	4
Top.....	5
<b>Setting up without the Toolkit.....</b>	<b>6</b>
Calibration .....	6
Change units.....	8
Change decimal places.....	8
Overload/underload alarm.....	8
Using TEDS .....	10
<b>Toolkit .....</b>	<b>11</b>
Toolkit overview .....	11

---

## Introduction/overview

The TRX allows simple display of strain bridge based measurements such as load cells and pressure gauges with input sensitivity from 0.5 mV/V up to +/-448 mV/V.

Up to six **calibration ranges** are available allowing for different loading modes (tension and compression) or different sensors. Each calibration range will remember settings that contribute to the **user experience** such as selected units and tare values.

TEDS devices using templates 33, 40 and 41 can be connected and will update the viewed calibration. The last twenty TEDS devices connected will be remembered and recognized when connected again reverting to the last user experience settings for that device. TEDS can be disabled and the internal calibration ranges become available again.

There are also up to six **display modes** available. These determine what is visible on the LCD display and what actions are available from the set of three soft keys.

Full configuration is available with a free PC based toolkit. Some simple configuration such as two point calibration is available from within the handheld using the **menu system**.

# Getting started

This document is designed to give a very quick overview of the TRX and its general, standard functionality. For more details, see the full manual.

## Hardware overview

### Front

#### Icons

Battery low and other warning icons

#### Primary display

Main values with description and units

#### Soft keys

Current soft key function

#### Soft keys

Perform the function shown on screen

#### Up/down

Function dependent on display state

1. Move through **calibration ranges** if available
2. Move selection up/down in **menu system**
3. Change values up/down of selected digit when setting limits etc

#### Left/right

- Function dependent on display state
1. Move through **display modes** if available
  2. Hold for 2 seconds to move **decimal place** left/right
  3. Change selected digit when setting limits etc

#### Info

Range name etc

#### Secondary display

Can be set to display other values such as max with description and units

#### Tertiary display

Can be set to display other values such as min with description and units

#### Power

Hold for 2 seconds to power up/down

#### OK

- Function dependent on display state
1. Open **menu system**, if available
  2. Select menu items
  3. Confirm changes
  4. Long press cancels changes




---

## Back





The Load Cell connector fitted to TRX Standard Product is BINDER 770-8. The cable fitted mating connector is a BINDER 771 8-way male connector. There are three versions available with different field cable diameters.



View from solder connector side of the connector

Cable pair	Suggested Colour	Connector Pin	Function
1	White	1	Loadcell Reference +ve
	Black	2	Loadcell Reference -ve
2	Green	3	Loadcell Signal +ve
	Black	4	Loadcell Signal -ve
3	Red	5	Loadcell Excitation +ve
	Black	6	Loadcell Excitation -ve
4	Blue	7	TEDS
	Black	8	Ground
Screen	Grey		Cable screen should <i>only</i> be connected to chassis of the sensor. If this cannot be achieved, then it should be connected to Excitation -ve.


# Setting up without the Toolkit

Quick, limited setup is possible using just the handheld and no toolkit. To access all the configuration features, you will need to use the toolkit.


## Calibration



Please note that this must be done in the correct order for the calibration to work correctly. Changing the **Sensitivity** after inputting mV/V readings will cause the calibration to be void. Always make sure you finish with **Apply**




'CALIBRATION'



'USER CALIBRATION'



'ENTER PASSWORD' (if set)




Scrolls through available characters



Moves between digits



'LIVE CALIBRATION'



'SENSITIVITY'



Select required input sensitivity



(Note, this **MUST** be selected before the following

steps)




Return to previous menu




'UNITS'


Select required calibration measurement type and units








Manually enter the low output required using  to select digits and  to change the value

 changes the sign of the entered number


 moves the decimal place to the left


 moves the decimal to the right

 to save changes (long press cancels changes and returns to previous view)




Manually enter the high output required (as above)


 to save changes (long press cancels changes)



Confirm or edit low mV/V input


(You can manually edit the mV/V to a value from a calibration certificate here)

 to save changes (long press cancels manual changes)



Confirm or edit high mV/V input

(You can manually edit the mV/V value to a value from a calibration certificate here)

 to save changes (long press cancels manual changes)

If everything is as planned






Return to previous selected display mode.

## Change units



In all standard display modes, scrolls through the available units for the selected calibration.

## Change decimal places



In all standard display modes, a 2 second press shifts the decimal place position for the selected units.

## Overload/underload alarm




Please note, the values saved for the thresholds are applied in the calibrated units of the currently selected range. This means that different ranges will trigger at different loads if the calibrated unit is different.




'ALARM'



'ALARM SOURCE'



Select 'GROSS' or 'NET'



Return to previous menu



'ALARM MODE'



Select 'NORMAL' or 'LATCHED'

(When the alarm is latched but no longer being triggered, cancel the alarm by:




'ALARM'



'\*\*ALARM CANCEL\*\*'






'ALARM THRESHOLDS'

'ALARM LOW'



Manually enter the low threshold required using  to select digits and



to change the value



changes the sign of the entered number



moves the decimal place to the left




moves the decimal to the right



to save changes (long press cancels changes and returns to display mode)



'ALARM HIGH'



Manually enter the high threshold required as above.



to save changes (long press cancels changes and returns to display mode)



Return to previous menu



'ALARM TRIGGER'



Select from:

- Disabled
- Outside limits (<low, >high)
- Inside limits (>low, <high)
- Above high (>high)
- Below high (<high)
- Above low (>low)
- Below low (<low)






Return to previous menu



'ALARM ACTION'



Select 'NONE', 'BEEP', 'FLASH' or 'BOTH'




Return to previous menu



Return to previous selected display mode.

## Using TEDS

Plug in a TEDS enabled load cell.



Message: 'NEW TEDS DEVICE USE SESSION DEFAULTS'  
TEDS table(s) will be automatically loaded.




Change selected TEDS calibration




Change displayed units


To disable TEDS and use the TRX's internal calibration:



'CALIBRATION'



'USER CALIBRATION'




'ENTER PASSWORD' (if set)




Scrolls through available characters



Moves between digits




The next time that you connect that TEDS device you will get the message:



## Toolkit

### Toolkit overview


More complex setup is possible using the supplied toolkit software. Install the toolkit onto your windows PC and connect the USB to the TRX. Then open the toolkit:



If only one TRX is connected then the toolkit will connect automatically.

Navigation is achieved using the icons along the top of the toolkit.

<p><b>Alarms</b> Set Alarm thresholds and actions</p>	<p><b>Calibration</b> 6 different calibration ranges available</p>	<p><b>Logging</b> Graph and logging of selected calibration</p>	<p><b>Settings</b> Set display and key functions.</p>	<p><b>Home</b> Disconnect and return to connection page</p>
---	--	---	---	---

The screenshot shows the PSD Toolkit interface with a top navigation bar containing icons for Alarms, Calibration, Logging, Settings, and Home. The main display area is divided into sections for Device Information, Status, and Information. Red arrows point from the icons in the top bar to their corresponding descriptions in the surrounding text.

<p><b>Measurement</b> Shows current readings, set update rate and quality Set resolution, zero mask, scale steady, system zero etc</p>	<p><b>Configuration</b> Customise the PSDs to only enable functions that you need</p>	<p><b>Import &amp; Export</b> Backup and restore all settings including option to clone</p>	<p><b>Information</b> About the current connected PSD</p>
--	---	---	---

For further information, please see the TRX User Manual.

Document Title: **TRX Quick Start Guide**  
Applies To: **Strain Gauge Sensor Display**  
Part Number: **517-952**  
Issue Number: **01.01**  
Dated: **4<sup>th</sup> January 2024**

*In the interests of continued product development, Mantracourt Electronics Limited reserves the right to alter product specifications without prior notice.*

